



LIGHTED PHANTOM COVERS 8220

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

• Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

• Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

• Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.

• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.

FITS: 2000-UP SOFTAIL MODELS (VERIFY SUFFICIENT CLEARANCE WHEN USED WITH SHOTGUN STYLE PIPES AND/OR SADDLEBAGS)

PART #	INCLUDED
608102LC	1 Left Lighted Phantom Cover Assembly – Chrome
608102RC	1 Right Lighted Phantom Cover Assembly – Chrome
200942	2 1/4"–20 x 7/8" H.H.C.S. Hex Bolts – Stainless Steel
408200C	2 Mounting Tab Clamps with 1/4" hole
200081	2 1/4" I.D. Internal Tooth Lock Washers – Zinc
200943	4 10/32 x 1/2" B.S.C.S. – Stainless Steel
200449	4 #10 Wave Washers – Stainless Steel
408200L	2 L Brackets
400834	4 T-Tap Clamshell Wire Splices
400846	4 Insulated Spade Connectors
400818	4 8" Nylon Cable Ties – Black
308220	1 Installation Instructions

THANK YOU FOR CHOOSING KURYAKYN!

TOOLS SUGGESTED

9/16", 7/16" Combination Wrenches, 1/8" Allen Wrench, Pliers

PROCEDURE

STEP 1 Identify the right and left side covers. Look into the lens of each LED light strip. When the covers are in place on the bike, the small individual LEDs should be positioned on top of the circuit board they're mounted to. This orientation will direct more light upward than down toward the road.

STEP 2 See PIC.1. Install the small tab clamp to the rear of each cover as shown – loosely for now. Use the 1/4"–20 x 7/8" hex head bolts and 1/4" I.D. internal tooth star washers.

STEP 3 See PIC.2. Loosen the rear axle adjuster lock nut – **DO NOT LOOSEN THE ADJUSTER!** Install the mounting brackets by sliding the brackets between the locknut and the frame as shown. Tighten the locknut against the bracket, firmly pinching the bracket into place.

-cont.-

PIC.1



PIC.2



STEP 4 See [PIC.3](#). "Hook" the rear tab clamp over the end of the Swing Arm where indicated. Using the 10-32 B.S.C.S. and #10 Wave Washers, fasten the "Phantom" covers to the mounting brackets. Tighten the 1/4" bolt at the rear of the cover to tighten the tab clamps.

WIRING PROCEDURE

Neatly run the wire harnesses along the back-side of the top swing arm tubes. Small nylon cable ties could be used here, positioned as inconspicuously as possible. Being sure to leave a small "loop" of wire to permit swing arm movement (be careful this slack wire will not get fouled in moving parts). Run the wires to the bikes rear fender wiring harness under the seat. Using the supplied wire splice clips, connect the black wires from the lighted Phantom covers to the bikes black wire. For running lights only, connect the red wires from the Phantom covers to the blue wire in the bike's harness. For auxiliary turn signal use, splice the red wires from the Phantom covers into the bikes violet wire for the left side, and the brown wire for the right.

Ride On!

Kuryakyn™

PIC.3



PAGE

2

LIGHTED PHANTOM COVERS

INSTALLATION