



INSTALLATION

SWINGWING PEGS

4466 & 4467

4466 FITS ANY MODEL WITH H-D STYLE MALE MOUNT FOOTPEGS.

4467 FITS MANY METRIC MODELS BUT REQUIRES MODEL-SPECIFIC ADAPTER, SOLD SEPARATELY

PARTS INCLUDED

- 1 SwingWing Peg Assembly (pr)
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

CAUTION! Prevent potentially serious injuries! Be sure all fasteners are secure before riding.

WARNING! IMPROPER INSTALLATION OR MISUSE OF THIS PRODUCT COULD RESULT IN SERIOUS PERSONAL INJURY OR DEATH.

METRIC NOTE You can purchase the appropriate adapters from the main Metric footpeg Web Page at www.kuryakyn.com.

METRIC NOTE When mounting on driver applications make sure the mount is allowed to move. Passenger Applications with solid stationary mount will not fold up.

TOOLS SUGGESTED

Set of hex wrenches, set of combination wrenches

PROCEDURE

STEP 1 Remove the existing footpeg; save the mounting hardware for re-use.

STEP 2 (METRIC ONLY) Place the adapter that you have purchased separately into the end of the SwingWing peg and just finger tighten the adjustment fastener in PIC.1.

STEP 2 Loosely fasten the left and right Switchblade Pegs to the footpeg mount on the motorcycle.

STEP 3 Adjust the angle of the footpeg on the male mount then secure with the footpeg fastener.

-cont.-



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



STEP 4 Check the angle for comfort; re-adjust if necessary. Repeat for the opposite side.

CLEAN THE PIN ASSEMBLY

Periodically clean the pin assembly of dirt and grime. Use a small amount of grease to keep the pin assembly working smoothly. See [PIC.1](#) and [PIC.2](#).

REPLACE THE RUBBER PADS

When the rubber pads become worn, replace them with Küryakyn P/N 4468/4469. Remove the footpegs from the motorcycle, then remove the fasteners securing the rubber pads, see [PIC.1](#). Install the new pads and secure with the fasteners.

Ride On!

