



# INSTALLATION

## FLAMED FLOORBOARD COVERS 7026

**FITS HONDA: ALL VTX 1800 AND VTX 1300 WITH FACTORY OEM FLOORBOARDS (RETRO, ETC.)**

### PARTS INCLUDED

- 1 Right Floorboard Cover
- 1 Left Floorboard Cover
- 1 Hardware Kit, including:
  - 6 1/4-20 x 7/8 Button Socket Cap Screw
  - 6 1/4 Flat Washer
  - 2 Curb Feeler
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

Strictly observe the following guidelines in order to use the product properly and avoid potentially dangerous accidents.

### THANK YOU FOR CHOOSING KÜRYAKYN!

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**WARNING!** IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**CAUTION!** Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**ATTENTION!** It is the installer's responsibility to ensure all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

### TOOLS SUGGESTED

Set of hex wrenches, combination wrenches or socket set and ratchet

### PROCEDURE

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**STEP 2** Remove the fasteners securing the rubber inserts to the stock floorboards; set the fasteners and rubber inserts aside, they will not be re-used.

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

· Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

· The product must be properly installed, maintained and operated under normal conditions.

· Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

· Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

· Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

· Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.

· Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



**STEP 3** Install the included curb feelers into the underside of the Flamed Floorboard Covers. Thread them into the holes shown in [FIG.1](#) and tighten.

**STEP 4** Position the Flamed Floorboard Covers over the stock floorboards; the inboard edge of the new covers should be within a 1/16" of the inboard side of the stock floorboards. See [FIG.1](#).

**STEP 5** Align the holes in the stock floorboards with the threaded holes in the new covers.

**STEP 6** Install three fasteners on each side, through the stock floorboards and into the new covers; do not fully tighten the fasteners until they are all installed.

**STEP 7** Ensure proper clearance and operation before riding the motorcycle.

*Ride On!*

**FIG.1**

