



ZOMBIE LEVERS FOR HONDA 7412

FITS: HONDA MODELS WITH HYDRAULIC CLUTCH, '02 -'08 VTX 1800 MODELS, '97-'04 VALKYRIE, (ALL MODELS EXCEPT RUNE) '85 -'96 SHADOW VT1100C

PARTS INCLUDED

- 1 Zombie Clutch Lever
1 Zombie Brake Lever
2 Lever Bushing
2 Grooved Emblem
2 Zombie Emblem
1 Alcohol Pad
1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KURYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches, and combination wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE FOR CLUTCH LEVER

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Remove the stock acorn nut on the bottom of the Clutch perch.

STEP 3 With a screwdriver, remove the threaded bolt that secures the clutch lever. Remove the lever from the housing, be sure to keep the brass plunger insert for the new zombie lever.

STEP 4 Install the new Zombie clutch lever with the brass plunger insert, and secure it with the stock bolt removed in step 3.

CUSTOMER SERVICE 877.370.3604 (toll free)

INSTALLATION QUESTIONS techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer...

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
• The product must be properly installed, maintained and operated under normal conditions.
• Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
• Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
• Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
• Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today-select the "CATALOGS" icon. Each Kuryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



**STEP 5** On the bottom of the clutch-housing you can reinstall the acorn nut removed in step 2 for the clutch lever. Be sure to not over tighten the acorn nut. Over tightening will cause binding.

## **PROCEDURE FOR BRAKE LEVER**

**STEP 1** Remove the stock acorn nut on the bottom of the brake perch.

**STEP 2** Remove the threaded bolt that secures the brake lever. Remove the lever from the housing.

**STEP 3** Install the new Zombie brake lever and secure it with the stock bolt removed in step 2.

**STEP 4** On the bottom of the brake-housing you can reinstall the acorn nut removed in step 1 for the brake lever. Be sure to not over tighten the acorn nut. Over tightening will cause binding and or brake drag.

**CAUTION!** Check brake light for proper function after installing the new brake lever.

**ATTENTION!** BE SURE THAT THERE IS NO BRAKE DRAG CAUSED BY THE INSTALLATION OF THE NEW BRAKE LEVER.

## **EMBLEM INSTALLATION**

**STEP 1** Clean surface areas with supplied alcohol pad.

**STEP 2** Dry fit the desired emblem before fully installing.

**STEP 3** When satisfied with the location, take the back of your fingernail and rub the tape backing to activate the catalyst.

**STEP 4** Remove tape backing and install emblem on the new lever. Apply pressure for 1 minute. Emblem will fully bond to the lever in 24 hours.

**STEP 5** Repeat the installation on the other lever.

**ATTENTION!** THE ADHESIVE WILL NOT BOND CORRECTLY IF APPLIED AT TEMPERATURES LESS THAN 50°F. DO NOT ATTEMPT THIS INSTALLATION IN TEMPERATURES LESS THAN 50°F.

*Ride On!*

**Kuryakyn®**

**PAGE**

**2**