



## AERO HEAD MARKER LIGHT

## 7458

**FITS: '01-'05 GL1800 ROTOR COVERS AND '06 GL1800 MODELS WITH THE PURCHASE OF P/N 7300 (ADAPTER PLUG) SOLD SEPARATELY.**

PART #	INCLUDED
7458	1 Pair of Aero Head Marker Lights Including: 2 LED Boards 2 Light Base Housing 2 Light Lens 2 Lens Trim 2 Wire Grommet 2 #6 x 3/8" Pan Head Screw 2 #2 x 1/4" Pan Head Screw
407458A	2 Adhesive Tape Pads
417458A	2 Adhesive Tape Pads
907316	10 4" Nylon Cable Ties 1 Hardware Kit Including: 2 Y Adapter Plug 1 Dielectric Grease 2 Alcohol Pads
307458	1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

### THANK YOU FOR CHOOSING KURYAKYN!

#### PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

#### IMPORTANT

Do not attempt to install this product if the ambient temperature is below 50 degrees. Poor adhesion could take place.

#### PROCEDURE

**STEP 1** Remove the chrome fork covers from the motorcycle. To do this the 4 fasteners shown in PIC.1 and PIC.2 will need to be removed.



-cont.-

#### CUSTOMER SERVICE

877.370.3604 (toll free)

#### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

#### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

#### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.



PIC.3



**STEP 2** Use the supplied alcohol pad to clean the area where the Aero Head Light will be secured.

**STEP 3** Pre-fit the light so you know its proper location. Remove the protective film from the adhesive tape on the back side of the light. Place the light into position then press and hold until proper adhesion has occurred. [PIC.3](#) shows the proper location of the light. There will be just a small amount of wire exposed if installed properly.

**STEP 4** "Peel back" the rubber boot at the base of each of the rear view mirrors. The turn signal light wiring and connector plug will be exposed. You can push your mirror to the front or rear to make it easier to work on the connectors.

**STEP 5** Neatly route the wires from the light so the terminated ends come out of the fairing at the rear view mirror bases. We suggest routing the wires along the brake hoses to the lower fork clamps and binding them with nylon cable ties. Be sure the remaining lengths of wire leading to the mirror bases are out of harms way. Remember to take into account the movement of the front end - both suspension and steering.

**STEP 6** Locate the connection plug between the mirror mounted turn signals and the fairing. Separate the plug, and install the supplied "Y" adapter plug in line. If you have other Küryakyn products like P/N 7312 Stealth Light Bar, P/N 7455 LED Front Reflector Conversion, or P/N 7513 LED Mirror Lights, there will already be one "Y" connector in place. This connector can be added to the existing one.

**STEP 7** Plug the Aero Head Marker light into one of the small plugs on the "Y" connector (the remaining one will be used for other Küryakyn accessories). Replace the rubber boots around the base of the mirrors.

**STEP 8** Reinstall the chrome fork covers that were removed in STEP 1. Make sure all fasteners are secure.

Use Dielectric grease on all electrical connections.

*Ride On!*