



INSTALLATION



CHROME INNER PRIMARY COVER 8294

FITS: '90-'06 DRESSERS, ROAD KINGS, ROAD GLIDE AND STREET GLIDE

PARTS INCLUDED

- 1 Chrome Cover
- 1 Small "L" bracket – Chrome
- 1 Large "L" bracket – Chrome
- 1 Plastic Clamp Jaw
- 2 Foam Pads with Adhesive Back
- 1 Button Head Cap Screw 10"–24 x 2" fully threaded – Chrome
- 1 #10 Flat Washer – Chrome
- 1 Socket Head Cap Screw – Chrome, 1/4"–20 x 1.35"
- 1 Wave Washer 1/4" I.D.
- 1 Flat Washer – Chrome .406 O.D. x .280 I.D. x .062 thick
- 1 Flat Washer – Zinc 5/16" I.D.
- 4 Machine Screw with Slotted Undercut Flat Countersunk Head 6"–32 x 1/4" Patched with Blue Loctite
- 1 Standoff Mounting Stud 5/16" External Thread, 1/4"–20 Internal thread
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

1/2" Socket Wrench, Torque Wrench, Straight Slot Screwdriver, 1/8", 3/16" Allen Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

-cont.-

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



PROCEDURE

STEP 1 See PIC.1. Install the two "L" brackets using the four 6"-32 x 3/8" screws. With the 10"-24 x 2" button head and #10 flat washer, LOOSELY install the plastic clamp jaw into the corresponding slot in the chrome cover. Place the two foam pads in the orientation shown.

STEP 2 See PIC.2. Remove the stock fasteners from the primary housing at the locations shown. Where the hex bolt was removed from the front of the inner primary case, install the standoff stud with the 5/16" flat washer. Torque to 18 FOOT POUNDS.

STEP 3 Set the chrome cover into position, and maneuver the plastic clamp jaw so it catches on the lip on the back side of the inner primary housing. Bolt the cover into position using the 1/4"-20 x 1.250 socket head cap screw, 1/4" wave, and flat washers at the front mounting point, and fasten the "L" brackets in place with the stock socket head cap screws removed from the outer primary in step one, as shown in PIC.2. Torque to 96 INCH POUNDS.

STEP 4 With your 1/8" allen wrench, tighten the 10"-24 x 2" button head closing the plastic clamp jaw on to the lip on the back of the inner primary housing. TIGHTEN THIS PLASTIC CLAMP SNUG ONLY OR YOU MAY STRIP THE THREADS OUT OF IT.

Ride On!

Kuryakyn

PIC.1



PIC.2



PAGE

2

INNER PRIMARY COVER

INSTALLATION