



INSTALLATION



DRIVING LIGHT BAR MOUNTING BRACKET 4009

FITS: HONDA 1100 SPIRIT, KAWASAKI 1500 AND 800 CLASSIC

PART #	INCLUDED
404009	1 Light Bar Mounting Plate, Stainless Steel
904009	1 Light Bar Mounting Kit Includes: 2 M8 x 1.25 x 16mm SHCS 18-8 2 M8 x 1.25 x 23.5mm Hex Spacer 2 M6 x 1.0 x 12mm BSCS 2 M6 x 1.0 x .394 O.D. x 17.5mm Hex Spacer
304009	1 Installation Instruction

Not all parts will be used. You will use either the M6 or the M8 screws, but not both.

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KURYAKYN!

NOTE

We recommend using Kuryakyn Part No. 2328, Universal Wiring and Relay Kit, to manually operate the running lights. It is important to use Loctite on all hardware when installing new parts.

PROCEDURE

- STEP 1** Add the two extension Hex Spacer nuts to the headlight bolts under the lower triple tree. Use either the M6 or M8 whichever one is correct for your bike.
- STEP 2** Position the mounting plate on to the extension nuts and fasten the plate using the two appropriate Socket Head Cap Screws.
- STEP 3** Position the new light bar on to the mounting plate and fasten using two screws supplied with the light bar.
- STEP 4** Route the wires under the mounting plate and up into the rear of the headlight.
- STEP 5** Remove the three Phillips screws on the headlight bezel. Carefully remove the bezel and bulb.
- STEP 6** Connect the turn signal wires to the corresponding O.E.M. wires inside of the headlight. (Refer to Factory Service Manual.) We recommend connecting both of the power leads from the driving lights to Kuryakyn P/N 2328, *Universal Wiring and Relay Kit*, or an equal quality relay switch.

-cont.-

CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.



WIRING COLOR CODES AND INFORMATION

L.E.D. AUXILIARY RUNNING LIGHTS AND TURN SIGNALS

COLOR	FUNCTION
Red	"Low" running light
White	"High" turn signal
Black	Ground

SILVER BULLET DRIVING LIGHTS

These halogen lights are grounded by their connection to the chassis. The single black wire from each light is the power wire.

STEP 7 Test for function of **ALL** the lights before re-assembling the headlight and bezel. Reassemble the headlight when all lights are functioning properly.

Ride On!

Kuryakyn™

PAGE

2