



INSTALLATION

FULL DRESSER BAG BY BAGTEC 4140

FITS MOST MOTORCYCLES EQUIPPED WITH A BACKREST OR LUGGAGE RACK

PARTS INCLUDED

- 1 Complete Bag and Rain Cover with Tie Down Mounting Straps
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

Thank you for purchasing your new FULL DRESSER. The most innovative backrest mounted motorcycle bag on the market. BAGTEC designed and Kuryakyn built, we know that you will be very pleased with its high quality and features.

The FULL DRESSER comes with a 30 day money back guarantee, unused of course (less shipping and handling), and a Kuryakyn backed three year quality and workmanship warranty. A name we have all come to know, trust and respect.

BASIC INSTALLATION

NOTE So as not to tear up your passenger seat or scratch your luggage rack, get a black hand towel and place it on your seat or rack before mounting bag.

LUGGAGE RACK MOUNTING

STEP 1 Set bag on the rack. If you have a wide backrest, then close the 10" wide Velcro strap tightly around the backrest. If you have a narrow backrest, pre-fit the strap size and slide bag over backrest.

STEP 2 Secure the included straps onto "D" Rings and snug the bottom straps to the saddlebag brackets, backrest bars, or taillights. You may also loop the straps through secure anchor points and back to other "D" rings on the bag.

STEP 3 Tightening Straps (stowed in the rain cover pouch). These straps tighten the bag to the back of the backrest. Attach one end of a Tightening Strap to the middle D-ring on one edge of the bag. Route the other end down and under the backrest pad and loop it back to the same middle D-ring and pull it tight. Repeat process on the other side.

STEP 4 Take a moment to ensure all connections are secure and any loose ends are neatly tucked away or tied down.

SEAT MOUNTING

STEP 1 Set bag on the rack. If you have a wide backrest, then close the 10" wide Velcro strap tightly around the backrest. If you have a narrow backrest, pre-fit the strap size and slide bag over backrest.

STEP 2 Secure and snug the bottom straps to the saddlebag brackets, backrest bars, or taillights. These straps are in the rain cover pouch).

STEP 3 Take a moment to ensure all connections are secure and any loose ends are neatly tucked away.

-cont.-

4140-15HD-0107

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.

kuryakyn.com



TIPS ON USING YOUR NEW FULL DRESSER MOTORCYCLE BAG

MAIN BAG ZIPPERS

For optimum placement always keep the main bag zipper handles to the left side of the bag in the middle. This will allow top or bottom access when out on the road.

HIDDEN POCKET ZIPPERS

Always keep the pocket zipper handles on the top of the pocket toward the front of the bike. Rain flaps extend greatly over the zippers for dryness. For easy use of the pocket zippers, fold the rain flaps back before trying to get to something out of the pockets.

STOP ROLLING THE BAG BEFORE STANDING IT UPRIGHT TO KEEP FROM FRAYING THE BOTTOM OF THE BAG.

NOTE

The FULL DRESSER is not a seat. It has a plastic interior shell that will crack if used as one. The FULL DRESSER is not an airline bag. If you have seen some of your luggage after baggage claim is finished with it, you will not even think of using your FULL DRESSER bag when you fly. However, if you are planning to meet your bike or rent one when you get there and would like to have your bag with you, we suggest you pack it and box it before checking it into baggage claim.

Ride On!