



INSTALLATION



TRANSFORMER™ THROTTLE BOSS 6294

FITS: KÜRYAKYN TRANSFORMER™, ISO®, AND ISO®-FLAME GRIPS

PARTS INCLUDED

- 1 Transformer™ Throttle Boss
- 1 Transformer™ Throttle Boss Plate
- 1 5/16-18 x 5/8 Socket Head Cap Screw
- 4 4-40 x 9/16 Socket Head Cap Screws
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches


STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Remove the four socket head cap screws in the end of the right side (throttle) grip. See PIC 1. Set the screws aside for now, they will be re-used.

PIC 1



CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
- Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Küryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Küryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



kuryakyn.com

-cont.-

STEP 3 Remove the transformer cap; set it aside.

STEP 4 Place the Throttle Boss plate over the exposed end of the grip. See PIC 2.

STEP 5 Place the end cap knurled spacer over the Throttle Boss plate. See PIC 3.

STEP 6 Place the transformer end cap with center stud over the end cap knurled spacer.

STEP 7 Secure the assembly together with the four screws removed in Step 2. Do not over tighten the screws.

STEP 8 Place the throttle boss "blade" on the throttle boss plate and secure it with the 5/16-18 x 5/8 Socket Head Cap Screw. The flat side of the "blade" needs to be flush with transformer grip. See PIC 4.

STEP 9 Ensure proper clearance and operation before riding the motorcycle.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

THROTTLE BOSS ADJUSTMENT PROCEDURE

STEP 1 Loosen the 4 socket head cap screws in the end of the grip. See PIC 5.

STEP 2 Adjust the position of the throttle boss as desired (See PIC 5) and retighten the screws; do not over tighten the screws. You can also change the positioning of the "blade" of the throttle boss by loosening the 5/16-18 x 5/8 Socket Head Cap Screw and rotating the "blade" portion to the best rider positioning.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

Kuryakyn[®]

PIC 2




PIC 3



PIC 4



PIC 5



Ride On!

PAGE

2